



Touring Motorcycle Enhancements that "Go the Distance"

800.279.9997
360.539.7981

www.firecreekacc.com
Quickdraw@firecreekacc.com

8518 Kimmie St SW
Olympia, WA 98512

Auxiliary Light Mirror Mount Brackets, 2018+ Gen-6 Goldwing

Parts List

- Right and Left Light Bracket
- 4 - 5mm X 25mm SS Socket Screws
- 4 - 5mm SS Flat Washers
- 4 - 5mm SS Lock Washers
- 2 - 5mm X 7mm Aluminum Spacers
- 2 - 5mm X 12mm Aluminum Spacers



Installation

1. Remove the mirror arm cover panel: Remove one 5mm setting bolt on the bottom of each panel. Pull out and rearward to snap the panels off.
2. Modify the mirror arm cover panel: Notice two unused 5mm bosses on the outer underside of the mirror arm. Drill two 5/16 to 3/8 inch corresponding holes in the mirror arm cover. Alternately, you may simply trim off the end of the panel to expose the threaded bosses.
3. Replace the mirror arm cover panels and check that your holes match the threaded boss locations. Adjust your holes if required.
4. Install our light brackets in the mirror arm bosses with the provided 5mm hardware: Pass the socket screws through the washers, light brackets, spacers and mirror arm cover. Tighten into the mirror arm bosses.

