



Template for Quicktank
Seat Pad (seat protection):
Use 0.50" - 1.00" thick Closed Cell Foam

Cut from paper or cardboard first to
make sure this will work for your needs.

Initial Installation will require forceful
pressure, down and back, to install
clamps to seat grab handels.